





Schurter




CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S

Dio brojeva:	CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S
Proizvođač / robna marka:	Schurter
Opis proizvoda	SWITCH PUSHBUTTON SPST 100MA 42V
Liste podataka:	 CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S.pdf
Status RoHS	 Bez olova / RoHS sukladni
Brod od	Hong Kong
Put pošiljke	DHL/Fedex/TNT/UPS/EMS

[ZAHTJEV ZA PONUDU](#)

Slika može biti reprezentativna. Pogledajte specifikacije za pojedinosti o proizvodu.













Specifikacije CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S

DIO BROJEVA	CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S
PROIZVOĐAČ	Schurter
OPIS	SWITCH PUSHBUTTON SPST 100MA 42V
STATUS SLOBODNOG OLOVA / ROHS-A	Bez olova / RoHS sukladni
OBRAZAC PODATAKA	 CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S.pdf
NAPONSKA VRIJEDNOST - DC	60V
NAPONSKA VRIJEDNOST - AC	42V
TIP	Capacitive, Illuminated
STIL ZAVRŠETKA	Wire Leads
FUNKCIJA PREBACIVANJA	Off-On
NIZ	CPS
DIMENZIJE IZREZIVANJA PLOČE	Circular - 19.10mm Dia
AMBALAŽA	Bulk
RADNA TEMPERATURA	-40°C ~ 60°C
VRSTA MONTAŽE	Panel Mount, Front
RAZINA OSJETLJIVOSTI VLAGE (MSL)	1 (Unlimited)
MEHANIČKI ŽIVOT	-
STATUS SLOBODNOG OLOVA / ROHS-A	Lead free / RoHS Compliant
ZAŠTITA OD ULAZA	IP67 - Dust Tight, Waterproof
NAPON OSVJETLJENJA (NOMINALNI)	5 ~ 28 VDC
VRSTA OSVJETLJENJA, BOJA	LED, Yellow/Red
ZNAČAJKE	Ceramic Actuator, RESET Symbol
ELEKTRIČNI ŽIVOT	-
DETALJAN OPIS	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
TREKUTNA OCJENA	100mA (AC/DC)
BOJA - AKTUATOR / KAPA	Clear (White Filter/Diffuser)
STRUJNI KRUG	SPST
VRSTA POGONA	Round, Button, Flush

Povezane oznake

Schurter CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Distributer CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Dobavljač CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S
Cijena CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Slike CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S slika
CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S PDF tablični list	CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S Preuzimanje tablice podataka	CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S list s podacima
Stock CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Kupite CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Kupite Schurter CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S
Schurter CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Dobavljač Schurter	Distributer Schurter
Schurter CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1073-S	

Povezani proizvodi

 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1067-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YWVAR-W1001-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>
 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1076-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1070-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>
 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1068-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1071-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>
 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1077-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1075-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>
 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1074-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YWVAR-W0000-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>
 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1069-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>	 <p>CPS19-LA00A10-SNCCWTNF-AI0YRVAR-W1072-S</p> <p>Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock</p> <p style="text-align: center;">RFQ</p>