




**CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S**

Dio brojeva:	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S
Proizvođač / robna marka:	Schurter
Opis proizvoda	SWITCH PUSHBUTTON SPST 100MA 42V
Liste podataka:	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S.pdf
Status RoHS	 Bez olova / RoHS sukladni
Brod od	Hong Kong
Put pošiljke	DHL/Fedex/TNT/UPS/EMS

ZAHTEJ ZA PONUDU

Slika može biti reprezentativna. Pogledajte specifikacije za pojedinosti o proizvodu.

Specifikacije CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S

DIO BROJEVA	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S
PROIZVOĐAČ	Schurter
OPIS	SWITCH PUSHBUTTON SPST 100MA 42V
STATUS SLOBODNOG OLOVA / ROHS-A	Bez olova / RoHS sukladni
OBRAZAC PODATAKA	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S.pdf
NAPONSKA VRIJEDNOST - DC	60V
NAPONSKA VRIJEDNOST - AC	42V
TIP	Capacitive, Illuminated
STIL ZAVRŠETKA	Wire Leads
FUNKCIJA PREBACIVANJA	Off-On
NIZ	CPS
DIMENZIJE IZREZIVANJA PLOČE	Circular - 19.10mm Dia
AMBALAŽA	Bulk
RADNA TEMPERATURA	-40°C ~ 60°C
VRSTA MONTAŽE	Panel Mount, Front
RAZINA OSJETLJIVOSTI VLAGE (MSL)	1 (Unlimited)
MEHANIČKI ŽIVOT	-
STATUS SLOBODNOG OLOVA / ROHS-A	Lead free / RoHS Compliant
ZAŠTITA OD ULAZA	IP67 - Dust Tight, Waterproof
NAPON OSVJETLJENJA (NOMINALNI)	5 ~ 28 VDC
VRSTA OSVJETLJENJA, BOJA	LED, Yellow/Cyan
ZNAČAJKE	Ceramic Actuator, G Symbol
ELEKTRIČNI ŽIVOT	-
DETALJAN OPIS	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
TREKUTNA OCJENA	100mA (AC/DC)
BOJA - AKTUATOR / KAPA	Clear (White Filter/Diffuser)
STRUJNI KRUG	SPST
VRSTA POGONA	Round, Button, Flush

Povezane oznake

Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Distributer CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Dobavljač CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S
Cijena CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Slike CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S slika
CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S PDF tablični list	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S Preuzimanje tablice podataka	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S list s podacima
Stock CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Kupite CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Kupite Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S
Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Dobavljač Schurter	Distributer Schurter
Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1007-S	

Povezani proizvodi

 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1003-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1004-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ
 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1009-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1010-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ
 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1008-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1011-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ
 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1013-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1012-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ
 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1006-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1002-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ
 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1001-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1005-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V Na lageru: Out stock RFQ